

The front SOA U-Bolts (quantity, part#, size and shape) you need for an '80's FSJ are:
1- DAY 361 – 431, 9/16 x 3-5/8 x 8-5/8, Round (diff side)
3 - DAY 361 – 414, 9/16 x 3 x 7-1/2, Round (1 diff, 2 tube side)
Those are Dayton part numbers, you can search for a dealer by state or zip code here:
http://www.daytonparts.com/DPweb/App_11/Info_site/info_enter_iframe.asp
Or just have a local spring shop make them up to those sizes.

The front SOA U-Bolts (quantity, part#, size and shape) you need for a pre 1980 FSJ are:
2- DAY 361 – 431, 9/16 x 3-5/8 x 8-5/8, Round (diff side)
2 - DAY 361 – 414, 9/16 x 3 x 7-1/2, Round (tube side)
Those are Dayton part numbers, you can search for a dealer by state or zip code here:
http://www.daytonparts.com/DPweb/App_11/Info_site/info_enter_iframe.asp
Or just have a local spring shop make them up to those sizes.

Some distributors are sort of picky about ordering U-bolts for retail sales.
You can expand your search with that link by using just the first 2 numbers of your zip code.

Rear FSJ Dana 44 and AMC20 U-Bolts:
4 - DAY 361 – 414, 9/16 x 3 x 7-1/2, Round (same as the tube side for the front).

Rear FSJ Dana 60 U-Bolts:
DAY 361 - 427
9/16 x 3-1/4 x 8 1/2" Round

Rear 14-Bolt U-Bolts:
DAY 361 - 383
5/8 x 3-1/2 x 9-5/8 Round